



Aqua TROLL® 800 Multiparameter Sonde

THE AQUA TROLL® 800 IS A FULLY CUSTOMIZABLE MULTIPARAMETER SONDE WITH INTERCHANGEABLE WATER QUALITY SENSORS AND A MOBILE APP INTERFACE THAT ENABLES SIMPLIFIED CALIBRATION, EASY SET UP AND AUTOMATIC DATA UPLOADS TO THE CLOUD.

The Aqua TROLL® 800 is a seven-port multiparameter sonde and data logger, including six sensor ports and a wiper port. There is an option to have an antifouling wiper to ensure data accuracy.

The Aqua TROLL® is optimized for long-term monitoring of water quality in the harshest environments. Monitoring experts appreciate low energy use that lengthens maintenance cycles, and an integrated LCD for checking deployment readiness, battery life and sensor status. Use as a standalone data logger, or protect your data in case of unplanned telemetry interruptions. All features are delivered through a simplified user experience that makes this advanced technology accessible to everyone.

SIMPLIFIED USER EXPERIENCE

All Aqua TROLL® products use our industry-leading ecosystem which is shared across instruments and includes:

- VuSitu mobile app with live data and in-app guidance through setup and calibration
- HydroVu software for anywhere, anytime data visibility of your data
- Data files that sync automatically to HydroVu for secure access on any device
- Sensors that can be used across multiple products, saving time and expense
- Common cables, communication device and VuLink telemetry



EXTENDED DEPLOYMENT DESIGN

The Aqua TROLL® 800 was designed with features that make it easier to extend deployments and reduce site-visit maintenance time.

- Interlocking sensors reduce surfaces for fouling
- Dual-sided antifouling wiper cleans sensors and restrictor simultaneously
- Optional copper restrictor

BUILT-IN ERROR PREVENTION

Prevent the most common damage or loss with:

- Spring-loaded screws that stay in place
- Smart sensors that fit in any port
- Wet-mate connectors that prevent water damage
- Anti-roll bumpers to keep equipment stationary
- Slip-clutch wiper that prevents motor damage
- Titanium Twist-Lock connector and Kevlar-reinforced cable

WIDE RANGE OF PARAMETERS AVAILABLE

Available sensors include Rugged Dissolved Oxygen (RDO®), temperature, conductivity, pH, ORP, turbidity, chlorophyll a, phycocyanin (BGA-PC), phycoerythrin (BGA-PE), fluorescent dissolved organic matter (FDOM), crude oil, Rhodamine WT, ammonium, chloride, and nitrate. Enable additional derived parameters, or calculate custom parameters from HydroVu. See the Aqua TROLL Sensors spec sheet for specifications and features.

LOWER CALIBRATION COSTS

The Aqua TROLL® 800 uses less than 100 mL of solution for most calibrations, reducing calibration cost by 5x over traditional methods and saving thousands of dollars in calibration solution per year. In-app instructions ensure consistency and accuracy with every calibration.



GENERAL		AQUA TROLL 800 MULTIPARAMETER SONDE	
OPERATING TEMPERATURE (NON-FREEZING)	-5 to 50° C (23 to 122° F) ISE: Ammonium & Nitrate 0 to 40° C (32 to 104° F); Chloride 0 to 50° C (32 to 122° F)		
STORAGE TEMPERATURE	Components w/o fluid: -40° C to 65° C (-40° to 149° F) (non-freezing water); pH/ORP: -5° C to 65° C (-23° to 149° F); Ammonium/Nitrate: 0 to 40° C (32° to 104° F); Chloride: 0 to 50° C (32° to 122° F)		
DIMENSIONS	Diameter: 7.2 cm (2.84 in) OD Length: 63.7 cm (25.08 in) Length With Bail: 74.7 cm (29.42 in)		
WETTED MATERIALS	Buna-N, Noryl, Nylon, Polyphenylsulfone, Polycarbonate, Acetal, EPDM/Polypropylene TPV, FKM Fluoroelastomer, Titanium, Fluorocarbon Coating, Ceramic, Acrylic Adhesive Film, Polyurethane Adhesive, Graphite, PC/PMMA Blend, Acrylic, Sapphire, PVC, Platinum, Glass, Proprietary RDO Sensing Formulation		
WEIGHT¹	3.23 kg / 7.12 lbs (includes sensors, batteries and bail)		
MAX PRESSURE RATING	Up to 350 PSI		
COMMUNICATION OPTIONS	RS-485/MODBUS, SDI-12, Bluetooth		
READING RATES	1 reading every 3 seconds		
DATA LOGGING	Store up to 50 log files		
LOGGING RATE	1 minute to 99 hours		
ENVIRONMENTAL RATING	IP68 with all sensors and cable attached IP67 without the sensors or cable attached		
INTERNAL MEMORY²	16 MB		
MICRO SD CARD³	8+ GB micro SD card included, user replaceable		
INTERNAL POWER	2 user-replaceable Alkaline D Batteries		
BATTERY LIFE⁴	> 6 months typical with wiping > 9 months typical with no wiping		
EXTERNAL POWER⁶	8-36 VDC (not required for normal operation); Sleep: <0.2 mA typical Measurement: 40 mA typical; 75 mA max		
HEX SCREW DRIVER	1.3 mm, 0.050 in		
COMMUNICATION DEVICE	TROLL Com Plus or VuLink		
CABLE OPTIONS	Vented or non-vented polyurethane or vented Tefzel® Twist-Lock or Flying Leads termination		
LCD DISPLAY	Integrated display shows status of sonde, sensor ports, connectivity, power information, battery capacity and data log status		
SOFTWARE	Android: VuSitu through Google Play and Amazon App Store iOS: VuSitu through Apple App Store		
CERTIFICATIONS	CE, FCC, WEEE, RoHS Compliant		
DATA SERVICES	HydroVu		

SENSOR	ACCURACY	RANGE	RESOLUTION/PRECISION	RESPONSE TIME	UNITS OF MEASURE
PRESSURE (OPTIONAL)⁵	±0.1% FS from -5 to 50°C	Non-Vented or Vented 0-10 m (0-33 ft) 0-30 m (0-98 ft) 0-100 m (0-328 ft) 0-250 m (0-820 ft)	0.01% full scale	T63<1s, T90<1s, T95<1s	Pressure: psi, kPa, bar, mbar, inHg, mmHg Level: in, ft, mm, cm, m, cmH2O, inH2O
BAROMETRIC PRESSURE	± 1.0 mbars	300 to 1,100 mbar	0.1 mbar	T63<1s, T90<1s, T95<1s	psi, kPa, bar, mbar, inHg, mmHg

NOTES: ¹Weight includes sonde, sensors, wiper, batteries, and bail. ²For 30 parameters >100,000 data records, > 3 years at 15 min. interval. A single data record includes timestamp, temperature, RDO, pH, ORP, turbidity and conductivity logged in Linear or Linear Average mode. ³Log data recorded to SD card in comma delimited variable (CSV) file format. Greater than 32 GB not supported. ⁴Logging all sensors at 15 min interval on 2 D Alkaline batteries. Battery life dependent on site conditions and wiping. ⁵User-defined reference. ⁶Current from an external power source must not exceed 4 amps.

For interchangeable sensor specifications, see the sensor spec sheet. Specifications are subject to change without notice.

WARRANTY: 2 year - Sonde, wiper. 1 year - Accessories. See warranty policy (www.in-situ.com/warranty) for full details. See the Aqua TROLL Sensors Spec Sheet for sensor warranty information.

in-situ.com

Copyright © 2026 In-Situ Inc. All rights reserved. March 2026

